

Step 1 :

Heat the film with the Ripack heat gun in order to seal it in the jaw of the machine



Step 2 :

Do it on all the width of the film



Step 3 :

Unroll the film to the correct length and cut it.



Step 4 :

You can prepare some bags in advance for your palettes.

